

## Installation Instructions for 52080 & 52085 Universal Radiator Mount

Available for: 28"x16.5", 22"x19", 24"x19", 26"x19", 28"x19" & 31"x19" Radiators

### Installation Instructions:

If using the mounting tabs the minimum recommended inside mounting distance on part numbers 52081 thru 52085 is 18-3/4", and on part number 52080 is 16-1/2". See Below.

**STEP #1:** Assemble the lower radiator support as shown, then using thru bolts with washers and Nylok lock nuts (not included) bolt radiator mount to core support or frame.

Urethane Vibration Isolators.  
Be sure to install with raised lip  
towards radiator core.

5/16"-18 Fasteners

When mounting to the  
face of an existing core  
support, square tubes  
may be drilled for thru  
bolts.

Lower mounting tabs may be removed  
if mount is to be installed with no lower  
core support. Welding may be required  
to provide a rigid mount if this is done.

**STEP #2:** Seat radiator into lower mounting isolators, then assemble the top of the radiator mount. Always mount a radiator from the raised ridge (or lip) portion of the tanks:

Fasten the top mounting tabs to the core  
support or frame so that they can be removed  
to allow removal of the radiator.

Mounting tabs may be  
drilled when mounting  
to a chassis tube or frame.

Min. Distance 18-3/4"  
(52081 to 52085)

Min. Distance 16-1/2"  
(52080)



1-800-345-4545 [jegs.com](http://jegs.com)