




Pull back on the ClickLockTM release and remove one corner from cab rail.



Feed tarp dowel into cab rail. (NOTE: For easiest feeding action, place tarp on a flat smooth surface, and keep dowel straight while feeding into cab rail. Caution, pavement may scuff tarp.)



Reinsert corner piece into cab rail until it "clicks" and locks into place.






Extang Corporation
1901 E. Ellsworth Rd.
Ann Arbor, MI 48108
734 677-0444, Fax: 734 677-8409


Visit us at:


WWW-Extang Corporation

WWW-Extang Corporation

Item No. 0023-1202 RH Printed in U.S.A.









Attach "U" clamp to side rail clamp with allen bolt. Insert side rail clamp

all the way into rail.

Note: For over-the-rail bed liners first refer

to Diagrams A and B below.









Tarp may be rolled up and secured with Velcro® for bulk hauling



For each clamp mark on your bedliner a $1-1/2'' \times 3''$ hole as shown above. Remove clamp. Cut holes in bedliner. Reinsert side rail clamp. Return to step 6.



Side rail clamped to bed with bow attached.