

BK054 INSTALLATION INSTRUCTIONS

REQUIRED TOOLS:


Wrenches and sockets: 13mm, 18mm, 21mm, 22mm

Jack and jack stands

Pry-bar (optional)

INSTALLATION:

1. Lift vehicle and safely support with jack stands under the frame rails. Do not put stands under the rear cradle as it will be necessary to lower the cradle for this installation.
2. Place the hydraulic jack under the differential and raise it to support the entire cradle/differential.
3. Using a 21mm socket, loosen the two rear cradle bolts but do not remove. Leave approximately 3/8" - 1/2" of thread engagement. (**IMAGE 1**)



4. Using a 21mm socket, remove the front two differential bolts. (**IMAGE 2**)
5. Remove the small bolts on the front cradle support brackets using a 13mm socket.
6. Using a 21mm socket, remove the two front cradle mounting bolts. (**IMAGE 3**)
7. Lower the front of the cradle down until the front of the differential bushings are accessible.

BK054 INSTALLATION INSTRUCTIONS

8. Assemble the 35mm bolt, washer, lock washer, and one of the aluminum pucks as shown in **IMAGE 4** and install it as an assembly. Thread the assembly into the front differential bushing as shown in **IMAGE 5** but do not tighten. Repeat for both front bushings.
9. Assemble the 65mm bolt, washer, and lock washer and thread it into the rear of the front differential bushing as shown in **IMAGE 5**.
10. Tighten all four front bolts until the lock washers are fully compressed.
11. Now remove the rear differential bolts.
12. Assemble the 100mm bolt, washer, lock washer, and one of the aluminum pucks and thread it into the rear differential bushing as shown in **IMAGE 6**.
13. Tighten until the lock washer is compressed.
14. Lift the cradle back up to the frame and insert the front cradle bolts and cradle supports.
15. Tighten the main front cradle bolts to 129 ft/lbs.
16. Tighten the smaller bolts on the front cradle supports to 41 ft/lbs.
17. Tighten the rear cradle bolts to 129 ft/lbs.
18. Lower vehicle.



WWW.BMRSUSPENSION.COM

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, buyer assumes all risk of any damage caused to the vehicle/person during installation or use of this product.