

FORD SUPER DUTY

Set Part # 20049

11-01-05 Rev-C

STEP 1.

Prior to Installation:

- A) **Fit:** Verify you have ordered the right flares for your vehicle make and model and check their fit.
- B) **Painting :**(Optional) if paint is desired it must be done prior to installing flares on the vehicle clean outer surface with a good grade degreaser. **DO NOT USE LACQUER THINNER OR ENAMEL REDUCER AS A DEGREASER.** Wipe outer surface thoroughly with a tack rag prior to paint.
Paint flares using a high quality enamel, or polyurethane automotive paint. (Application of a primer coat is optional)
If painting edge trim (not recommended) use a flex additive.
- C) **Performance:** Using larger Tires may increase the area required to turn the vehicle. Some Tire/Rim combinations may require lowering bump stops and or installing steering stops to prevent tire from contacting flare.
- D) **Exhaust System:** Modifications may be necessary to maintain a minimum 4" clearance between flares and exhaust pipes. (Exhaust gases should not vent directly onto flares)



TOOLS FOR EASY INSTALLATION

- Utility Knife
- #2 Phillips Drive bit
- Drill motor, 5/16 Bit
- ½ Wrench
- 7/32 Socket, 10 mm Socket
- Socket Wrench
- Marker

FLARE INSTALLATION PROCEDURES

STEP 2:

Preparing the Work Area (Front and Rear)

Remove factory fender trim and mud flaps (when installed).

STEP 3: Edge Trim Installation

(See Illustration #1)

- A) Peel two to three inches of red vinyl backing away from edge trim tape. Applying the adhesive side of the edge trim to the inner side of the flare, affix the edge trim to the top edge of the flare (the portion that comes in contact with the side of the vehicle).
- B) Press edge trim into place along the top edge of the flare in one-foot increments, pulling red vinyl backing free as you continue to work your way around the top edge of the flare.




Illustration #1

**STEP 4: (Front and Rear Flare)
Stain steel screw Installation
(See Illustration # 2)**

- A) Using the indents on backside of pockets in flare as a guide drill a 1/4 hole.
NOTE: DRILL HOLES BEFORE PAINT.
- B) Insert stainless steel screw and washer into front of flare, secure with jam nut, using supplied Torx bit. **(See illustration #2)**




Illustration #2

**STEP 5: Front Flare Installation
(See Illustration # 3)**

- A) Remove the 3 factory hex screws from wheel well using the 7/32 socket.
- B) Hold flare in place on fender, applying moderate pressure to outside surface of the flare; fasten using the factory hex screw removed earlier.




Illustration #3

**STEP 6: Rear Flare Installation
(See Illustration # 6)**

- A) Remove factory 10mm bolt with 13mm nut at lower front of wheel opening. **(See illustration #4).**
- B) Hold flare in position with moderate pressure. Using the holes in the flares as a guide, mark wheel well lip where each hole is.
- C) Remove flare and stick a black Mylar tab over each marked location. Slide supplied clamps over each tab location. **(See illustration #5)**
- D) Hold flare in position and line up the holes in flare to the threaded holes in clamps. Starting with the two corner holes, start the supplied screws but keep loose.
- E) Insuring the flare is properly located on fender, install remaining screws and applying moderate pressure to outside surface of flare, tighten screws, beginning with the two corner locations and then the two bottom screws. Tighten the top center screw last.




Illustration #4




Illustration #5