

56010

MAZDA MPV

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.




¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filée.

02/18/09



English

1. Open the rear hatch. Remove the vehicles rear scuff fascia panel. **[A]** On the drivers side remove the vehicles two plastic pushpins from the rear trim panel, cargo net anchor hooks, and jack storage cover. **[B][C]** Repeat on the passenger's side.

2. On the drivers side carefully pull back on the rear trim panel to access the back side of the vehicles taillight wiring harness connected to the back of the taillight assembly. Separate the connectors making sure not to damage the locking tabs. **[D]** Insert the T-connector end with the yellow wires in-between the separated housings making sure the locking tabs are in place.

3. Route the T-connector end with the green wire to the passenger side along the backside of the rear storage compartment under the removed rear scuff fascia panel. Insert the T-connector end with the green wire in-between the separated housings on the passenger's side.

4. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

6. Route the 4-flat wire out from under the rear trim panel. Route the 4-flat wire to the center of the vehicle and out of the rear hatch when in use. When not in use roll up and store in an out of the way location in the rear storage compartment. Replace anything removed during installation.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.



56010