

56011

HONDA CIVIC
HONDA FIT
MAZDA 3
MITSUBISHI GALANT
HONDA ACCORD COUPE

WIRING LOCATION GUIDE
GUÍA DE UBICACIÓN DEL CABLEADO
IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

2/03/2011

English

CIVIC, GALANT, MAZDA 3, AND HONDA FIT

1. Open the trunk/hatch and on both sides of the vehicle remove rear access cover (A) (B). Remove the vehicles cargo area floor covering and rear scuff panel (C). Inside the rear access panel locate the vehicles taillight wiring harness connectors (D). The connectors will be similar to those on the T-Connector. On the driver side separate the connectors from the backside of the taillight assembly.

HONDA FIT ONLY

Make sure to use the blue 3-pin connector not the green 3-pin connector (E).

HONDA ACCORD COUPE

1. Open the trunk and remove the spare tire cover and jack storage tray. Remove the rear scuff panel by removing one plastic fastener and pulling up (C). On both the driver and passenger side of the trunk remove two plastic fasteners holding the felt trunk liner in place (F). Pull back on the felt trunk liner and locate the vehicle's taillight wiring harness connectors (G). The connectors will be similar to those on the T-Connector harness (H).

2. On the driver side insert the T-Connector ends with the yellow and red wires between the separated connectors (I). Make sure the connectors are fully inserted with locking tabs in place.

3. Route the T-Connector end with the green wire out from under the drivers side trim panel across the removed scuff panel and under the passenger side trim panel. Repeat Step 2 on the passenger side using the T-Connector end with the green wire only separating the 3-pin connector.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. On the driver side locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-connector with the cable ties provided.

6. Route the 4-flat wire to the center of the vehicle and out the trunk when in use. When not in use roll up and store in an out of the way location in the rear cargo area.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

