

56040

SUBARU FORESTER SUBARU OUTBACK WAGON SUBARU XV CROSSTREK

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

10/28/2013



INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

English

1. Open the tailgate and remove cargo area cover (A). Under the cover remove the trays from the center and the driver side of the vehicle (B) by removing the plastic fasteners holding them in place (C).

2A. 2009-2013 Forester- The harness connector is on the driver side under the trays (D,E).

2B. Outback Wagon- The harness connector is tucked up behind the driver side inner fender trim, just visible near the rubber grommet in the floor and the cargo anchor (F).

2C. XV Crosstrek / 2014 Forester- The harness connector is on the driver's side. Pull back on the rear trim panel to locate the vehicle's harness connector (G,H).

3. Insert the harness connector into the vehicle's connector taking care that it is fully inserted with locking tabs in place (I).



4. Adhere the black converter box to the frame of the car using the double-sided tape provided. Secure any loose parts of the T-Connector with the cable ties provided.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surfaces before drilling to avoid damage to vehicle and/or personal injury.

5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using eyelet and screw provided.

6. Install red 10 amp fuse into the inline fuse holder.



7. Reinstall all items removed during install.

8. Route the 4-flat wire to the center of the vehicle and out the hatch when in use. When not in use roll up and store in an out of the way location in the rear cargo area.

IMPORTANT:

Battery connection must be fuse protected, 10 amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire.

