

# 56110 FORD F-150

## English

### WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



#### MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

#### ¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

#### À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

10/26/2010

1. Locate the vehicle's OEM trailer wiring harness connector on top of the spare tire support on the driver side (A,B). The connector will be similar to the one on the 4-Flat harness.


2. If the vehicle does not already have a 4-Flat harness connected remove the cover from the connector. If the vehicle has a 4-flat harness connected separate the connectors taking care not to damage the locking tabs. Insert the new 4-Flat harness connector into the vehicle's harness connector. Make sure the connector is fully inserted with locking tabs in place.

#### WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

3. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.

4. Route the 4-Flat back to the rear of the vehicle secure in a convenient out of the way location near the hitch.



56110

**INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813**