

56161 HONDA ODYSSEY

English

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.

¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

8/17/2012

1. Open the rear hatch and remove the floor covering and rear scuff panel. On the passenger side partially remove the rear trim panel (A). Behind the trim panel locate the vehicles rear junction box.
2. Insert the harness into the top right corner of the vehicle's junction box (B). Make sure the connector is fully inserted with locking tabs in place.
3. Adhere the black converter box to the frame of the car using the double-sided tape provided.
4. Insert the 10 AMP fuse provided into the inline fuse holder to complete the install.
5. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white ground wire using ring terminal and screw provided.
6. Route the 4-flat wire out from under the rear trim panel, along the removed scuff panel, and under the driver's side rear trim panel.
7. Reinstall all items removed during installation. Secure any loose wires with the cable ties provided.
8. Locate fuse compartment on passenger side kick panel, near glove box. Remove the fuse panel cover and insert the 10 amp fuse provided into position #5 (C,D).
9. When in use route the 4-flat wire to the center of the vehicle and out of the hatch. Roll up the 4-flat wire and store in jack compartment when not in use.

INSTALLATION QUESTIONS? CALL TECHNICAL SUPPORT AT 1-800-798-0813

