



**#3266 TORQUE-CURVE MPFI SPACER**  
2000-02 Tundra 4.7L  
2001-02 Sequoia 4.7L  
1998-02 Land Cruiser & LX470 4.7L

## INSTALLATION INSTRUCTIONS

**Important!** Read all instructions before you begin installation.

THIS KIT CONTAINS		TOOL LIST	
1 - Hamburger's Performance Spacer	2 - 8mm X 95mm Bolts	13mm Socket	
3 - O-Rings	2 - 8mm X 70mm Bolts	3mm Hex Key	
1 - 6mm x 20mm Flat Head Screw	2 - 5/16" Nylon Lock Nuts	Standard Screwdriver	
1 - 6mm x 1" Spacer Plate	2 - 5/16" Lockwashers		
1 - Extension Plate	2 - 5/16" Bolts		

- 1. DISCONNECT NEGATIVE (-) BATTERY CABLE.**
- Remove the air intake hose assembly.
- Remove the (2) nuts from throttle linkage (keep nuts, reused in step 8).
- Remove the throttle body cover bracket and install 6mm x 1" Spacer Plate using (1) 6mm x 20mm Flat Head Screw (this will relocate the cover bracket 1" forward).
- Remove the throttle body.
- Install the (3) O-Rings on Hamburger's Spacer.
- Install the Hamburger's Spacer with throttle body using (2) 8mm x 95mm bolts & (2) 8mm x 70mm bolts. **Note: The O-ring side of the spacer faces the throttle body.**
- Reinstall throttle linkage extension plate reusing 2 factory nuts removed during step 3.
- Install the throttle linkage onto the extension plate using (2) 5/16" bolts, (2) 5/16" lockwashers and (2) 5/16" nylon lock nuts.
- Inspect and Test throttle linkage for full open & closed positions before driving.
- Reinstall the air intake hose assembly.
- Reconnect negative battery cable.