



## P/N 2136HKR (painted) & 2136-1HKR (ceramic coated) SUPER COMPETITION FULL LENGTH HEADERS

1970-81 Camaro (265-400)  
1975-79 Chevy II & Nova (265-400)

**NOTE:** Reducers are available with oxygen sensors on 1980 and later models, 2 1/2" bolt-on P/N 11045HKR & 3" bolt-on P/N 11046HKR.

**NOTE:** Will not fit angle plug heads.

Thank you for making HOOKER HEADERS your choice in a high-performance exhaust system. Extensive dyno/track testing has enabled HOOKER to offer the most advanced design in exhaust systems. The installation, while not complex, will take a certain amount of time. However, the additional horsepower and improved performance will more than justify your efforts. Proper installation and maintenance will ensure long life and maximum performance from your hooker exhaust system.

**WARNING! Breaking in an engine with ceramic-coated headers WILL result in damage to the coating and will VOID all warranties. Ceramic-coated headers require several heat cycles to fully cure before they will withstand extreme heat. HOOKER recommends using a cast-iron exhaust manifold or an old header to break in new engines to avoid coating damage.**

### **BEFORE STARTING**

Your vehicle must be raised a minimum of 36 inches. A floor hoist is ideal. If no hoist is available, we strongly urge the use of axle stands as a safety measure. **CAUTION! YOUR CAR SHOULD NOT BE SUPPORTED ON A BUMPER JACK.**

### **INSTALLATION PROCEDURE – PLEASE READ CAREFULLY**

1. Disconnect the battery cable to prevent damage to the electrical systems. Remove the spark plugs and spark plug heat shields.
2. Unbolt the stock exhaust pipes and push aside. Remove the stock exhaust manifolds.

### **LEFT SIDE:**

1. Remove the dipstick tube, air conditioning compressor, and clutch linkage (if equipped).
2. Starting from below, work the header up through the chassis into position over the exhaust ports.
3. Start the header bolts. Power steering models must use the stock bolt and furnished spacer in the first bolt hole. **See Figure A.**
4. Tighten the header bolts evenly.
5. Replace the dipstick tube, spark plugs, and clutch linkage (if removed). The air compressor requires Hooker bracket, P/N 10925HKR, for remounting. **See Figure B.**

### **RIGHT SIDE:**

1. Remove the starter.
2. Starting from below, work the header up through the chassis into position over the exhaust ports.
3. Insert the gasket between the header flange and head. Start the first and last header bolts.
4. With the header loose, bolt the starter into place. Check the starter wires for adequate header clearance.
5. Start the remaining header bolts. Tighten all bolts evenly.
6. Install the spark plugs and reconnect the battery.
7. To connect the collectors to the headers, purchase Hooker Reducer (P/N 11030HKR).

**NOTE:** A dual exhaust system can be fabricated using either Hooker Super Competition Turbo Mufflers (21104HKR, 21105HKR, or 21106HKR); or Hooker Competition Turbos (21004HKR, 21005HKR, or 21006HKR); and Universal Tailpipe (16215HKR).

8. When finished, give your vehicle a test drive, checking carefully for any new noises. After several days of driving, retighten all bolts.

Any questions? Please contact Technical Service: 1-866-GOHOLLEY or 270-781-9741. For online help, please refer to the website: [www.holley.com](http://www.holley.com).




Figure A




Figure B

**LIMITATION OF LIABILITY – DISCLAIMER:**

The regulation of emissions production, noise levels, and safety standards is undertaken by the federal government, each of the fifty state legislatures, and by many local municipalities, towns, and counties.

HOKKER makes no warranties of merchantability, of fitness for particular purpose, or that its products are approved for general use, or that its products are approved for general use, or that its products comply with laws, regulations, or ordinances in the state where they may be sold to the ultimate purchaser, the consumer.

Unless expressly stated to the contrary in the catalog, instruction sheet; or price list, the entire risk as to the conformity of any company product in any such state and as to repair should the product prove to be defective or non-conforming, is on the retail purchaser, the buyer, the ultimate consumer, of such product and it is not upon the seller, distributor, or manufacturer.

In this connection, the retail purchaser, the buyer, the ultimate consumer assumes the burden of the entire cost of any and all necessary service, alterations, or repair.

**THE FOREGOING STATEMENT LIMITS THE LIABILITY OF THE MANUFACTURER.**

California vehicle code, sections 27156 AND 38391, prohibits the advertising, offering for sale, or installation of any device, which modifies a vehicle's emission control system, unless exempted, unless otherwise noted. HOKKER Headers have not received an exemption from these code sections and are to legal for sale or use in California on vehicles originally equipped with catalytic converters, it is illegal, except for racing vehicles, which may never be driven upon a highway. To remove or otherwise render inoperative any emission control device on the regulated motor vehicles – check catalog listings to ensure proper application in the other 49 states, unless otherwise noted, HOKKER Headers are not legal for pollution-controlled motor vehicles, except for racing vehicles, which may never be used upon a highway and are not intended or applicable for highway use.

**2136HKR**

**Date: 11-28-05**