

Installation Instructions for 159080 to 159096 Fuel Pressure Regulator Mounting Brackets

Important Note

All regulators will mount below the bracket except for the JEGS Regulators which will mount above the bracket. It may also be necessary to space the bracket upward, depending on manifold profile and carburetor type. The carburetor studs on the regulator side will need to be replaced with a minimum of 1/4" longer studs depending on the use of spacers.

1. Read all of the Instructions Before Beginning the Installation.
2. Determine correct direction of bracket, it will only fit one way correctly. This can be determined by simply slipping bracket over the carburetor studs and checking for throttle linkage interference. Make sure that the throttle will open and close without interference. (**Note:** On late model Holley 4500 Series Carburetors it is necessary to shim bracket upward with spacers supplied.) All brackets are designed to work on right side of carburetor – passenger side.
3. Mount the regulator to the bracket using the supplied hardware as indicated in the chart below.
4. Mount the regulator and bracket assembly to carburetor studs.
5. Make the appropriate fuel lines. (**Note:** If braided line is used then it is recommended to use #6 line due to the bending radius.)

Regulator Brand	Regulator Part #	Carburetor	Mounting Bracket Part #	Included Hardware
Magna-Fuel	MP-9833, MP-9433	4150/4160	159081 & 159091	(4) #10-24 Screws (4) #10 Spacers
		4500	159086 & 159096	(4) #10-24 Screws (4) #10 Spacers (2) 5/16" Spacers
JEGS	15906 & 15907	4150/4160	159080 & 159090	(4) #8-32 Screws (4) #8 Spacers
		4500	159085 & 159095	(4) #8-32 Screws (4) #8 Spacers (2) 5/16" Spacers



1-800-345-4545 jeps.com