


2010 Ford Mustang 4.6L Competition Axle Back System



Warning: When working on, under, or around any vehicle exercise caution. Please allow the vehicle's exhaust system to cool before removal, as exhaust system temperatures may cause severe burns. If working without a lift, always consult vehicle manual for correct lifting specifications. Always wear safety glasses and ensure a safe work area. Serious injury or death could occur if safety measures are not followed.

-NOTICE- Fascia needs to be modified (cut) to install this Magnaflow exhaust system.

Step 1: (Carefully read all instructions before installation) To remove the OEM mufflers, first locate clamp junction at the inlet section of both mufflers. Remove the clamp from both the passenger and driver side, then remove the hangers from the rubber isolators (two on each side). Do not damage the OEM rubber isolators as they will be reused to mount your new Magnaflow system. Remove the mufflers.

Step 2: At this point you will need to cut the fascia to allow installation of the new exhaust system. Using the supplied template in the hardware kit enlarge the exhaust openings in the fascia following the instructions printed on the template. (see Fig.1)

Step 3: Once the fascia has been modified use the supplied 2.50" clamps to secure the MAGNAFLOW Competition Series Mufflers to the exhaust system. Locate all hangers to the rubber isolators.

Step 4: With all components mounted loosely, adjust the system for overall aesthetics and clearance of frame & bodywork. (MAGNAFLOW recommends at least 1/2" of clearance between the exhaust system and any body panels to prevent heat-related body damage or fire.)

Step 5: Once a final position has been chosen for the new system, evenly tighten all fasteners from front to rear. The OEM clamps must be VERY tight to properly align the pipes and prevent leaks (Approximately 40ft-lbs). Inspect all fasteners after 25-50 miles of operation and retighten if necessary.



Fig. 1

**** Magnaflow Performance Exhaust recommends professional installation on all their products**