



Technical Support Line: (952) 985-5675 Email: Info@QA1.net

INSTALLATION INSTRUCTIONS

QA1 REV™ Series Carbon Fiber Driveshafts for 2005-2019 Mustang GT, 2015-2018 GT350,
2015-2017 Mustang EcoBoost
QA1 P/N JJ-21206 through JJ-21220

• LEGAL DISCLAIMER NOTICE •

THIS COMPOSITE DRIVESHAFT PRODUCT AND RELATED COMPONENTS ARE SOLD AS-IS WITHOUT ANY WARRANTY WHATSOEVER, EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. QA1 ASSUMES NO RESPONSIBILITY OR LIABILITY FOR THE SELECTION, INSTALLATION, OR ANY USE OF THE PRODUCTS. THE END USER ACKNOWLEDGES THAT THE PRODUCT WILL BE USED FOR RACING AND ASSUMES ANY AND ALL RISKS RELATED TO SUCH ACTIVITIES. THE END USER AND ANY PERSON WHO INSTALLS THIS PRODUCT AND RELATED COMPONENTS ARE SOLELY RESPONSIBLE FOR DETERMINATION OF THE SUITABILITY OF THE PRODUCT AND COMPONENTS SELECTED. THE END USER INSTALLS AND USES THE PRODUCTS AND COMPONENTS AT THEIR OWN RISK AND AGREES TO FULLY INDEMNIFY QA1 AGAINST ANY CLAIMS DAMAGES OR LOSSES RESULTING FROM THE SELECTION, INSTALLATION, OR USE OF THE PRODUCTS OR RELATED COMPONENTS.

ONLY EXPERIENCED AND QUALIFIED PERSONS SHOULD INSTALL THE PRODUCTS AND COMPONENTS. IF YOU ARE NOT QUALIFIED TO SAFELY PERFORM THE INSTALLATION OF THE PRODUCT OR RELATED COMPONENTS, PLEASE CONTACT A REPUTABLE SHOP OR PERSON TO PERFORM THE WORK. FAILURE TO PROPERLY INSTALL THE PRODUCT OR RELATED COMPONENTS MAY RESULT IN VEHICLE DAMAGE, PERSONAL INJURY OR DEATH.

WARNING: Be sure to inspect all components regularly, especially following an accident. Do not use any components which may have been damaged.

WARNING: Composite driveshafts are fragile and if dropped or damaged will be considered scrap and should be replaced.

TOOLS AND SUPPLIES REQUIRED

- Floor Jack
- Jack Stands
- Blue Loctite 242
- Torque Wrench (lb. ft.)
- Metric Wrench Set
- Ratchet & Metric Sockets
- 12 mm 12 point socket
- 8 mm & 10 mm Allen sockets

Removal of Factory Driveshaft


1. Raise the vehicle and support with jack stands on a stable surface. See the vehicle owner's manual for jacking locations.
2. Disconnect and remove the exhaust system between the catalytic converters and mufflers.
3. Make alignment marks on the factory driveshaft at both the front and rear yokes. This will ensure the balance should the OE driveshaft ever be reinstalled in the car.
4. Remove the three (3) or four (4) bolts from the transmission output shaft.
5. Remove the six (6) bolts from the pinion yoke.
6. Support the driveshaft and remove the two (2) hanger bearing bolts. **Caution: The OE driveshaft assembly is heavy and can cause injury if not properly supported during removal.**
7. Remove the driveshaft from the vehicle.




Figure 1

Installation of QA1 Carbon Fiber Driveshaft

Note: The CV joint, CV adaptor and balance weights are color coded for driveshaft balance. The orientation of these components is critical for proper balance. See **Figure 2 & 3** below.



1. Thoroughly clean the mating surfaces on the pinion yoke and transmission output shaft of dirt, grease and corrosion. **Figure 4**
2. Remove the aluminum CV joint adapter from the driveshaft and install it on the vehicle's pinion flange using thread locker and the M10 x 35mm bolts supplied in the package. Ensure the adapter is fully seated in the pinion flange as the bolts are tightened. **Torque these bolts to 47 lb. ft.** Applying the parking brake will help prevent the pinion from rotating.
3. Attach the front of the driveshaft to the transmission using thread locker and the M12 bolts supplied in the package. Ensure the driveshaft flange yoke is properly seated against the transmission output as the bolts are tightened. **Torque these bolts to 85 lb. ft.**




4. Apply thread locker to the remaining six (6) 10 mm bolts and bolt the CV joint to the adaptor on the pinion flange. Ensure the colored marks on the adapter and the CV joint are lined up. See **Figure 2**. **Torque the bolts to 47 lb. ft.**

- With the rear suspension at ride height (or unloaded for '15-'18 car with IRS), check the distance from the tube end to the CV joint as shown in **Figure 5**. This should be measured at either side of the shaft rather than the bottom due to driveline angles affecting the measurement. Ensure the measurement is in the range listed below. See the **Table 1** for the specification according to the model year.
- Rotate the driveshaft and check for clearance around the driveshaft.
- Reinstall the exhaust system and verify there is clearance between the driveshaft and exhaust.

Table 1

Year	Dimension 'A' Range
2005 to 2010	2 ²⁵ / ₃₂ " to 2 ²⁹ / ₃₂ "
2011 to 2014	2 ²⁷ / ₃₂ " to 2 ³¹ / ₃₂ "
2015 to 2018	2 ¹ / ₂ " to 3"



Washing Recommendations

It is recommended to wash the composite driveshaft with soap and water only. Avoid contact with chemicals.

Dedicated Technical Support Team

QA1 is dedicated to providing quality support and instructions. We employ passionate racers and car enthusiasts that know our products and the industry to better serve you.

Check out our tech videos at www.YouTube.com/QA1Tech for:

- Frequently Asked Questions
- Quick Tips
- Install Information
- Tuning and Repair Guides
- Other technical information


Or call to speak with one of our experts: 1.800.721.7761

*Our technical support and order lines are open Monday - Friday, 8 am to 5 pm CST.

 [Facebook.com/QA1Motorsports](https://www.facebook.com/QA1Motorsports)

 [Twitter.com/QA1Motorsports](https://twitter.com/QA1Motorsports)

 [Instagram.com/QA1Motorsports](https://www.instagram.com/QA1Motorsports)



www.QA1.net/Tech