

INSTALLATION INSTRUCTIONS - INS107

2005 - 2009 Ford Mustang GT & GT500

LONG TUBE HEADERS

Part # 1641, 16410, 16415, 1649, 16490 and 16495



Install Time: Approximately 6 Hours.



Difficulty: Difficult.



Additional Parts required (sold separately) for installation:
O2 SENSOR 4 WIRE HARNESS EXTENSIONS
12" - Part # 1676

Please Note:
BBK O2 Sensor Harnesses
are **no longer** included in this kit -
Must be purchased separately.



MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.


UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 1

Disconnect the negative battery terminal.

STEP 2



Remove the bolt that secures the dipstick tube to the driver side cylinder head and pull the dipstick tube straight up to remove it from the engine.

STEP 3

Life the vehicle up as high as possible and unplug all the oxygen sensors.

STEP 4



Separate the cat-back system by loosening the 2 nuts on each band clamp and prying the locking tabs up with a small screwdriver while sliding the clamp towards the rear of the car.

STEP 5

Unbolt the stock H-Pipe from the collectors and remove the H-Pipe from the car.

DRIVER SIDE

STEP 6



Remove the bolts from the top and bottom of the steering shaft and remove the shaft. You may find more working space by removing the motor mounts from the engine by removing the nuts that secure the mounts to the K-Member and carefully jacking the motor up and supporting it with a block of wood, then removing the fasteners that attach the mounts to the engine block.

DO NOT ATTEMPT TO LIFT THE ENGINE BY JACKING UNDER THE OIL PAN.

 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019

FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 7



Remove the stock exhaust manifold and gasket. (Some of the manifold bolts are easier to access while working under the hood)

STEP 8

Install the BBK Header and supplied gasket. NOTE!!! On some applications it may be easier to re-use some of the original style stud type hardware.

STEP 9

Insert and finger tighten the supplied collector studs, and re-install the motor mount and dipstick tube.

PASSENGER SIDE

STEP 10



Unbolt and remove the starter from the bell housing.

STEP 11

Remove the stock exhaust manifold and gasket. (Remove the motor mount from block if needed)

STEP 12

Install the BBK Header and supplied gasket. Insert and finger tighten the supplied collector studs, and re-install the motor mount and starter.

STEP 13

Lower the motor mounts onto their mounting studs and tighten the nuts.

MADE IN U.S.A.

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019



FOLLOW THESE INSTRUCTIONS CAREFULLY TO ENSURE CORRECT FITMENT AND OPERATION

STEP 14

Re-install the steering shaft.

STEP 15

Install matching short X-Pipe (BBK 1636 or 1637) using supplied hardware.

STEP 16

Install the oxygen sensors into the BBK Headers and X-Pipe.

Re-connect the negative battery terminal. **NOTE!!!** After driving the car for a few hours its always a good idea to check and re-tighten the header bolts.

 **MADE IN U.S.A.** 

IMPORTANT: All appropriate safety equipment and gear must be used during the installation of this or any BBK Performance products or any time you work on a vehicle. BBK Performance accepts no responsibility for injuries or damage caused by or during the installation of this product.

UPDATED LAST: March 2019