

56094

CHEVROLET EQUINOX
GMC TERRAIN

WIRING LOCATION GUIDE GUÍA DE UBICACIÓN DEL CABLEADO IDE D'EMPLACEMENT DES FILS



MUST READ FIRST!

All steps must be followed to ensure correct function of the T-Connector. To verify proper installation once installed, test by connecting a test light or properly wired trailer.



¡DEBE LEERSE PRIMERO!

Debe seguirse todos los pasos para asegurar el correcto funcionamiento del Conector-T. Para verificar la correcta instalación, pruebe conectando una luz de prueba o un remolque debidamente cableado.

À LIRE D'ABORD!

Pour assurer le bon fonctionnement du T-Connector, il faut suivre toutes les étapes. Pour vérifier que l'installation a été bien effectuée, branchez un feu de test ou une remorque correctement filéée.

9/29/2010



English

1. Open the rear hatch. On each side of the vehicle remove the taillight assemblies by removing two fasteners holding each in place (A,B).

2. Behind the driver side taillight locate the vehicle's taillight wiring harness (C). The harness will have connectors that are similar to those on the T-Connector harness. Separate the connectors taking care not to damage the locking tabs. Insert the T-Connector end with the yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.


3. Route the T-Connector end with the green wire down through the opening under the driver side taillight (B). Under the vehicle route the T-connector end with the green wire across the backside of the bumper (D) and up through the opening under passenger side taillight. Repeat Step 2 on the passenger side using the green wire. The 4-flat should end up near the center of the vehicle.

WARNING!

Verify miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and/or personal injury.

4. Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle's frame or drill a 3/32" hole and secure white wire using eyelet and screw provided.

5. Secure the 4-flat to the center of the vehicle in a convenient out of the way location. Secure any loose wires with the cable ties provided.



56094