

## **Installation Instructions**

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

#### PRO-KIT # 4089.140

#### 2013+ Honda Accord, Sedan, 3.5L V6

Kit Contents	Description	Part Number	Qty	
	Front Spring, Left	4089.001	1	
	Front Spring, Right	4089.011	1	
	Rear Spring	4076.002	2	
	Bump Stop, Front	BS770014	2	
	Information Kit	EPAK	1	
	Instructions	4089.140INST	1	






### NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- **Never use impact wrenches or** impact guns to install or remove shock absorber piston components, shafts and piston rod nuts.
- PRO-KIT springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the PRO-KIT Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
  - Wheel alignment such as camber, caster & toe
  - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
  - Brake line clearance and attachments
  - Brake anti-locking and anti-skid system sensors
- **Tire Rotation**: In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.
- For MacPherson Strut type front suspension, it is important to mark the orientation of the upper perch with respect to the lower perch before disassembly. This orientation must remain the same with the installation of the Pro Kit springs. Noise may result if this procedure is not performed correctly.





# Additional Eibach Performance Suspension Components Available For Your Car:

Eibach Kits	Part Number	Description	Front	Rear
Pro Alignment	5.67540K	Rear Alignment Kit Camber +/- 3.0 Deg.	OE	Call
		Toe +/- 1.0 Deg.		
		Setback +/- 1.0 Deg.		