



Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

PRO-LIFT # E30-59-005-01-20

2003-2009 Lexus GX470

Note: The Pro Truck Leveling springs must not be used with the OE shocks. Extended travel shocks are required to avoid damage to the suspension.

Note: Please refer to the instructions on the following page for proper spring fitment when using the Eibach Pro Sport Truck Dampers

Kit Contents	Description	Part Number	Qty
	Front Spring	F31-59-005-01-FA	2
	Instructions	E30-59-005-01-20INST	1


NOTES: Read All Instructions Before Beginning Installation

- Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.
- Use of a hoist is highly recommended and will substantially reduce installation time.
- Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.
- Never use impact wrenches or impact guns to install or remove shock absorber piston components, shafts and piston rod nuts.
- **PRO-LIFT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, and tubing should be retained from the stock springs and used when installing the **PRO-LIFT** Springs.
- After installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors

Additional Eibach Components Available For Your Truck

Eibach Kits	Part Number	Description	Front	Rear
Pro Truck Sport Leveling front dampers	E60-59-005-01-10	Off-Road Performance	+0-2.5"	N/A
Pro Truck Sport Leveling rear dampers	E60-82-008-02-01	Off-Road Performance	N/A	0-1"

Spring Seat Fitting Instructions for Eibach Pro Sport Truck Dampers



Important: Ensure that the snap ring is fully seated in the snap ring groove (you should be able to rotate the snap ring manually/by hand). **Note: Improper installation will cause permanent damage to the shock. Please refer to the Pro Truck Sport Damper instructions for more info regarding proper installation and fitment.**

Notes:

- Do Not use the top groove in conjunction with the Eibach Pro Lift Spring. Doing so will cause damage to the suspension and a possible loss of control of vehicle.
- The 2nd and 3rd snap ring grooves are to be used to accommodate extra weight, such as heavy duty bumper, winch, and other miscellaneous modifications that may contribute to a lower overall ride height.
- Use of the 2nd and 3rd grooves to get more than 2" of lift on a stock vehicle may cause a degradation of ride quality.
- Average lift measurements shown are for Pro Truck Sport Dampers when used in conjunction with Eibach Pro Lift Springs. The lift amounts are based on a stock vehicle with no added aftermarket accessories or additional weight.



Installation Instructions

Eibach Springs, Inc. • 264 Mariah Circle • Corona, California 92879-1751 • USA • Tech Support 800-222-8811 Ext 114

PRO-LIFT # E30-59-005-01-02

2003-2009 Lexus GX470

Note: The Pro Truck Leveling springs must not be used with the OE shocks. Extended travel shocks are required to avoid damage to the suspension.

Kit Contents	Description	Part Number	Qty
	Spring, Rear	F31-59-005-01-RA	2
	Upper Spring Perch Adapter	8001271	2
	Lower Spring Locator	8001288	2
	Screw, Hex M12-1.75 x 40mm L	H13025576	2
	Nut, M12-1.75 Nylock	H63025500	4
	Washer, M12 Flat	H50025200	2
	Washer, Fender	H57085200	2
	Screw, Hex, M12-1.75 x 30mm L	H13155542	2
	Zip Tie	H70065500	1
	Instructions	E30-59-005-01-02INST	1

NOTES: Read All Instructions Before Beginning Installation

- **Only qualified mechanics experienced in the installation and removal of suspension components should perform this installation.**
- **Use** of a hoist is highly recommended and will substantially reduce installation time.
- **Never work on or under a vehicle unless it is properly supported by safety stands and wheels are blocked.**
- **Never use impact wrenches or impact guns** to install or remove shock absorber piston components, shafts and piston rod nuts.
- **PRO-LIFT** springs should be installed with the Eibach Logo right side up. All original stock spring isolators, dampers and tubing should be retained from the stock springs and used when installing the **PRO-LIFT** Springs.
- **After** installation, it is always important to inspect and adjust the following if necessary:
 - Wheel alignment such as camber, caster & toe
 - Tire and/or wheel fender clearance, when aftermarket tires and wheels are used.
 - Brake line clearance and attachments
 - Brake anti-locking and anti-skid system sensors
- **Tire Rotation:** In order to increase the life of your tires, it is recommended to rotate your tires every 3,000 miles.

Rear Suspension Removal and Installation

1. Raise the rear of the vehicle until the wheels are off the ground and the suspension is fully unloaded. **Note:** Never work on or under a vehicle that is not supported by the proper safety equipment.




Photo 1

2. Disconnect the air compressor electric connections as shown. (See Photo 1)



Photo 2

3. Disconnect the air lines from the compressor as shown. (See Photo 2)




Photo 3



Photo 4

4. Unclip the air bag air lines from the frame as shown. (See Photos 3 & 4)



Photo 5

5. Loosen and remove the hardware that secures the end link to the anti-roll bar, then, disconnect the end link from the bar. (See Photo 5)




Photo 6



Photo 7



Photo 8

6. Support the rear axle with a screw jack and disconnect the shock electrical connection, then, loosen and remove the hardware that secures the upper and lower shock mounts and remove the shock from the vehicle. (See Photos 6, 7 & 8)



Photo 9




Photo 10

7. Located on top of the spring pocket, disengage and remove the spring clip retainer, also disconnect the air line. (See Photos 9 & 10)





Photo 11



Photo 12

8. Lower the axle downward to remove some pressure from the air ride assembly, then, rotate the assembly 90 degrees to release the lower mount, then, remove the assembly and air lines as shown. (See Photos 11 & 12)



Upper Spring Adapter

Photo 13




Photo 16





Photo 14



Photo 17

9. Install the upper spring mount adapter using the provided M12-1.75 x 30mm L hex screw and M12 washer and nylock nut as shown. (See Photos 13 & 14)

10. Secure the lower spring mount adapter to the axle using the provided M12-1.75 x 40mm L hex screw and M12 washer and nylock nut as shown. (See Photos 15, 16 & 17)



Lower Spring Adapter

Photo 15



Photo 18



Photo 19



Photo 20

11. Install the rear spring making sure the spring lines up with the upper and lower adapters, then, raise the suspension upwards as shown. (See Photos 18, 19 & 20)

12. Install your new extended length shocks.



Photo 21

13. Reconnect and secure the OE end links with the OE hardware. (See Photo 21)




Photo 22

14. Secure the air compressor electrical connections with the provided zip ties. (See Photo 22)

15. Doublecheck to make sure everything is properly positioned and tightened.

16. Road test the vehicle and re-tighten if necessary