



64-72 A/Body, 78-88 A/G Body

Front Bar Installation

1. Look carefully at the current installation.
2. This installation can be performed without removing the front wheels . Always use proper safety devices such as jack stands or lift jacks to properly support the vehicle.
3. Loosen front bushing retaining bolts, leave a few threads engaged to support the bar.
4. Remove the factory end link from the car.
5. Support or hold the center of bar and carefully remove front bushing bolts.
6. Remove factory bar from vehicle, taking note of the placement of the swaybar bushings.
7. Using the included white silicone grease, grease the inside of the urethane 1 7/16" in sway bar bushings. (The silicone grease can be cleaned up with WD40.)



8. Install the urethane bushings on the bar. Make sure you position the bushing so when the bar is installed in the vehicle, the split will face the front of the car.
9. Place the bushing's bracket over top the bushing.



10. Install the new swaybar into the car using the included Cap Screws on the new brackets. This step will take some manipulating, as the original car was designed for a very small sway bar. You will need a 1/4" or a 6mm Allen Driver Socket for this. Our swaybar set is a much larger diameter than stock bar, and our Heavy Duty sway bar bushings and brackets are larger as well. You might find it easier to slightly squeeze the brackets together in a vice to allow you to better align the bracket holes with the original factory holes. Using a ratchet or air impact, install the screws with a washer under each head. This does work very well, you just need to use some torque to install these bolts. Have patience with this step.



11. Install the new A-Arm endlinks using a ratchet and wrench.
12. Tighten end link nut to the point where the end link bushing's diameter is just larger than it's support washer.




Rear Bar Installation

1. Look at the current sway bar installation.
2. Support the vehicle by the frame with lift jacks or jack stands, allowing the suspension to be unsupported.
3. Remove the four bolts holding the sway bar to the trailing arms.
4. Remove the factory sway bar from the vehicle.
5. Place the new Hotchkis swaybar up to the trailing arms and push the bolts through the sway bars.
6. Tighten up the new bar.
7. Double check that all fasteners are tightened.

Your installation is finished. Enjoy your new sway bars!







HOTCHKIS PERFORMANCE WARRANTY POLICY

Effective January 1, 2000. Supersedes all previous policy statements. Policies are subject to change without notice. Hotchkis Performance is not responsible for printing errors.

If you purchased your Hotchkis Performance product from an authorized dealer, you are covered by the terms of this policy. All claims however, must be submitted **THROUGH YOUR DEALER** not to *Hotchkis Performance* directly.

Return Policy:

We want you to be completely satisfied with your Hotchkis Performance product. In case you're not, you can exchange or return it within 30 days of the purchase date. To obtain a full refund, excluding freight, please contact our Customer Service Department at (562) 907-7757. You will be assigned a Returned Goods Authorization Number (RGA). The package you return must show the RGA on the outside of the package, include the original invoice and be shipped prepaid to our facility. The part has to be in its original packaging materials and be in a sellable condition. For parts presenting signs of use, only warranty claims will be accepted. Exchanges or refunds can be made after 30 days with a 20% restocking charge.

Warranty Claim:

Hotchkis Performance warrants its products against materials and workmanship failure for the term of 36 months (3 year) from the date of purchase and only up to the amount paid. If the product is determined to be defective, Hotchkis Performance will repair, replace or refund its value at Hotchkis Performance's discretion. Any repaired or replaced product will be returned to the sender freight prepaid.

How to File a Warranty Claim:

The answer to **ALL** the following questions should be **YES** before contacting our Customer Service Department.

- Is the part appropriate to your application?
- Did you carefully and thoroughly read the instructions provided along with the part?
- Do you have the proof of purchase?
- Are you the original purchaser?
- Is the part unmodified and clean?
- Is the return date within 36 months from the purchase date?
- Is the reason for return a legitimate product defect?

If the answer to all these questions is YES, please contact our Customer Service Department at (562) 907-7757. You will be given a Returned Goods Authorization Number (RGA) valid for 60 days. You will also be asked to ship the part prepaid to our facility. All shipments **MUST** be prepaid, include the original invoice and show the RGA on the outside of the package, otherwise it will be refused. Please include a brief explanation letter in order to expedite the warranty analysis process.

What doesn't this Warranty Cover?

The costs not covered by this warranty include but are not limited to:

- Removal, installation, shipment and insurance costs.
- Improper installation or maintenance.
- Misuse or abuse, negligence, off-road and/or racing applications.
- Damage to related components.
- Normal wear and tear.
- Costs incurred due to down time of vehicle.
- Alterations on the original design or unauthorized repairs.

Items offered but not manufactured by Hotchkis Performance are warranted according to the manufacturers terms and are not the responsibility of Hotchkis Performance.

All warranties implied by law are limited in duration of this warranty. You have specific rights that may vary from state to state.

12035 BURKE ST. SUITE 13 SANTA FE SPRINGS, CA 90670

PHONE: (562) 907-7757 FAX: (562) 907-7765



HORSEPOWER FOR YOUR SUSPENSION

RETURN THIS FORM FOR A FREE 9" DIE CUT STICKER!

Thank you for purchasing our products.

Our goal is to supply you with the highest quality, and the most thoroughly tested performance products available. To assist us in continuing to do this, please take a moment to fill out and return this questionnaire.

Name: _____

Address: _____

City: _____ **State:** _____ **Zip** _____

Phone #: _____ **E-Mail:** _____

Year, make and model, car/truck: _____

What parts did you purchase? _____

Where did you purchase them? _____

Were you satisfied with this transaction? **Y N**

(If not, why?) _____

• **WERE YOU SATISFIED WITH THE FOLLOWING?**

Fabrication and finish: _____

Instructions and ease of installation: _____

Performance improvement: _____

(If not, why?) _____

What other products would you like to see us make?



Have you read about our products on the Internet? **Y N**

(If so, where?) _____

Where have you seen our products?
(i.e. magazines/shows/catalogs) _____

12035 BURKE ST. SUITE 13 SANTA FE SPRINGS, CA 90670
PHONE: (562) 907-7757 FAX: (562) 907-7765

