

Installation Instructions for 10659 Woven Wire Wrap Chassis Kit Self-Vulcanizing Tape

The following steps show how to properly apply the “self-vulcanizing tape” included in JEGS Woven Wire Wrap Chassis Kit

You will need scissors.


Step One: Pull approximately 4 inches from the roll.



Step Two: Cut the 4 inch piece off with scissors.



Step Three: Peel off the clear plastic liner.



Step Four: While stretching the tape over the breakout make a full wrap around the loomed wires.



Step Five: While stretching out the tape wrap it around the other breakouts.



Step Six: Be sure to maintain tension on the tape while wrapping the breakout.



Example of finished breakout.



Helpful Tools to Have

555-10667 1/2" to 5/8" Tool

555-10666 1/4" to 3/8" Tool

555-10669 1/4" to 7/8" 3pc Tool Kit



Woven Wire Wrap Chassis Kit Contents

6 ft. – 1 in. Woven Braid Wrap
10 ft. – 3/4 in. Woven Braid Wrap
30 ft. – 1/2 in. Woven Braid Wrap
60 ft. – 1/4 in. Woven Braid Wrap
15 ft. – 1/8 in. Woven Braid Wrap
4 ft. – 3/8 in. Heat Shrink
5 ft. – 1/4 in. Heat Shrink
2 ft. – 1/2 in. Heat Shrink
100 – 4 in. Tie Wraps
100 – 7 in. Tie Wraps
1 Roll – 30 ft. Electrical Tape
1 Roll – 10 ft. Self-Vulcanizing Tape



1-800-345-4545 jeps.com