

**Ultra™
Drive**



Highly Styled, Low Cost Serpentine Drive

Installation Instructions

Ultra Drive Chevy Small Block

#20250, #20270, #20275 (without Power Steering)

#20260, #20280, #20285 (with Remote Power Steering)



Parts List

Alternator Front Bracket P/N 20251

- 1 20251-A Alternator Bracket Body
- 1 S270 $\frac{3}{8}$ " x $3\frac{1}{2}$ " Lg Soc Hd Bolt
- 1 S272 $\frac{3}{8}$ " x $3\frac{3}{4}$ " Lg Soc Hd Bolt
- 1 S278 $\frac{3}{8}$ " x 5" Lg Soc Hd Bolt
- 1 S622 $\frac{3}{8}$ " Lock Nut
- 1 BS3-.750 $\frac{3}{8}$ " Id x $\frac{3}{4}$ " Lg Steel Bushing

Alternator Rear Support Brk P/N 20252

- 1 20252-A Alternator Rear Support Body
- 1 S244 $\frac{3}{8}$ " x $\frac{3}{4}$ " Lg Soc Hd Bolt
- 1 S546 M8 x 100mm LgMetric Hex Hd Bolt
- 1 AC3-.200200" Lg Alum Spacer
- 1 TP3-.650 $\frac{3}{8}$ " Id x .650 Lg Tube Spacer

AC Front Bracket P/N 20253

- 1 20253-A AC Front Bracket Body
- 1 S272 $\frac{3}{8}$ " x $3\frac{3}{4}$ " Lg Soc Hd Bolt
- 1 S274 $\frac{3}{8}$ " x 4" Lg Soc Hd Bolt
- 1 S546 8mm x 100mm LgMetric Hex Hd Bolt

AC Support Bracket P/N 20254

- 1 S309 $\frac{3}{8}$ " x 1" Lg Button Hd Bolt
- 1 S311 $\frac{3}{8}$ " x $\frac{3}{4}$ " Lg Hex Hd Bolt
- 1 S557 M8 x 120mm Metric Soc Hd Bolt
- 2 S666 $\frac{3}{8}$ " Id x $\frac{3}{4}$ " Od Flat Washer
- 1 S750 Brass Heater Hose Extension

Wing Front Mount P/N 20255

- 1 20255-A Wing Front Mount Body
- 2 S120 $\frac{1}{4}$ " x $\frac{3}{4}$ " Flat Hd Bolt

Tensioner Bracket/Cover P/N 20256

- 1 20256-A Tensioner Bracket Body
- 1 20256-B Tensioner Cover Body
- 1 781-A Tensioner Front Cover Body
- 2 S248 $\frac{3}{8}$ " x 1" Lg Soc Hd Bolt
- 2 S250 $\frac{3}{8}$ " x $1\frac{1}{4}$ " Lg Soc Hd Bolt
- 1 S268 $\frac{3}{8}$ " x $3\frac{1}{4}$ " Lg Soc Hd Bolt

Power Steering Bracket P/N 20257

For Kit # 20260 Only

- 1 20257-A Power Steering Bracket
- 1 20257-B Power Steering Cover
- 2 S248 $\frac{3}{8}$ " x 1" Lg Soc Hd Bolt
- 2 S250 $\frac{3}{8}$ " x $1\frac{1}{4}$ " Lg Soc Hd Bolt
- 2 S550 M8 x 20mm Lg Metric Soc Hd Bolt

Pulley Kit P/N 20250-208 / 20260-208

- 1 6266-A Crank Shaft Pulley
- 1 6267-A Water Pump Pulley
- 1 208-A Alternator Pulley
- 1 222-A Alternator Fan
- 2 307-A Alternator Cap
- 1 331-A Water Pump Pulley Cap
- 1 392-A AC Cover
- 1 650-A Power Steering Pulley
For Kit # 20260 Only
- 1 780-A Tensioner Pulley Cap Mount
- 3 S025 $\frac{8}{32}$ x $\frac{5}{8}$ " Lg Soc Hd Bolt
- 3 S028 $\frac{8}{32}$ x 1" Lg Soc Hd Bolt
- 3 S124 $\frac{1}{4}$ " x $\frac{3}{4}$ " Lg Button Hd Bolt
- 3 S144 $\frac{5}{16}$ " x $\frac{7}{8}$ " Lg Soc Hd Bolt
For Kit # 20260 Only
- 4 S186 $\frac{5}{16}$ " x $\frac{7}{8}$ " Lg Fine Thd Soc Hd Bolt
- 3 S292 $\frac{3}{8}$ " x 1" Lg Fine Thd Soc Hd Bolt
- 1 S685 $1\frac{1}{16}$ " Id Split Lock Washer

Accessories

- 1 P112 Alum Water Pump
- 1 P313 Power Steering Pump Remote
For Kit # 20260 Only
- 1 P412 Air Compressor Chrome
- 1 P416 AC Line Adaptor
- 1 P568 Alternator Chrome
- 1 P750 Belt Tensioner

Required Tools and Materials

RTV Silicone
Loc-Tite® Thread Locker
Anti-seize Compound
Gasket Scraper, Steel Wool or Sandpaper to clean gasket surfaces
 $\frac{3}{16}$ " Allen Head Driver
 $\frac{5}{16}$ " Allen Head Driver
 $\frac{1}{4}$ " Allen Head Driver
6mm Allen Head Driver
 $\frac{5}{8}$ " Combo Wrench

$\frac{9}{16}$ " Combo Wrench
 $1\frac{1}{16}$ " Combo Wrench
 $\frac{3}{4}$ " Combo Wrench
Socket Wrench & Extension
10mm 12pt. socket
12mm 12pt. socket

Serpentine Belt

61" for Kits Without Power Steering
62" for Kits With Remote Power Steering

Preparing to Install

- Disconnect the battery to prevent accidental engagement of starter motor.
- Drain coolant from system
- If your A/C is intact and charged it must be evacuated. This is best done by a professional garage with proper recycling equipment
- Remove the existing alternator, air conditioning compressor and associated brackets.
- Remove all pulleys and water pump.
- Remove all traces of old gasket and sealer with gasket scraper and steel wool pad.
- Clean threads in block by chasing with appropriate thread chasers.

Installing the Kit

Photo-1 Ensure the sealing face of the coolant outlets are clean, flat and free of old gasket material. Using new gaskets install the Water Pump (P112), along with A/C Bracket (20253-A) and Alternator Bracket (20251-A). In the A/C Bracket use one $\frac{3}{8}$ x 4" SHCS (S274) in the lower hole, and a $\frac{3}{8}$ x 3 $\frac{3}{4}$ " (S272) in the upper hole. In the Alternator Bracket use a $\frac{3}{8}$ x 5" SHCS (S278) in the upper hole, and a $\frac{3}{8}$ x 3 $\frac{3}{4}$ " SHCS (S272) in the lower hole. *Note the Alternator Bracket Mounts To the Drivers Side*



Photo-3 Install the Crank pulley (6266-A) Using (3) $\frac{3}{8}$ x 1" SHCS (S292).




Photo-2 Install The Water Pump Pulley (6267-A) and the Water Pump Cap (331-A) using (4) $\frac{5}{16}$ x $\frac{7}{8}$ " Long Fine Thread SHCS (S186) as shown.



Photo-4 (NOTE Skip steps on power steering build for non power steering kits) Install the Power Steering pulley (619-A) to the Remote Power Pump (Press Fit) and (740-A) Cover.

Photo-5 Install the Power Steering Pump into the Cover (20257-B) and thru the back of the cover use (2) M8 x 20mm SHCS (S550)





Photo-6 Building the Power Steering Bracket (20257-A) and (20257-B) use (2) $\frac{3}{8}$ x 1" SHCS from the rear of the bracket to mount the cover as shown.




Photo-7 Mount the Power Steering unit to the Drivers side lower bolt holes using (2) $\frac{3}{8}$ x $1\frac{1}{4}$ " SHCS Note: The line fittings point down towards the steering box.

Photo-8 Mount the Tensioner Cover(20256-B) to the Tensioner Base Bracket (20256-A) using (2) $\frac{3}{8}$ x 1" SHCS (S248). Note the slot in the cover will be pointing to the bottom of the bracket.




Photo-8 1. Hold Tensioner Body in a vise to remove bolt & washer from tensioner pulley. Note: Bolt is a left handed thread, turn clockwise to remove. Install the Tensioner into the 20256-B Bracket cover use a $\frac{3}{8}$ x $3\frac{1}{4}$ " SHCS and install the (781-A) cover as shown and bolt into place.

Photo-9 Disregard the tensioner washer and replace with the (780-A) adapter as shown and reinstall the tensioner pulley.



Photo-10 Install the Tensioner unit to the two lower passenger side holes using (2) $\frac{3}{8}$ x $1\frac{1}{4}$ " SHCS (S250).



Photo-11 Mount the Alternator into the main bracket (20251-A). Use one $\frac{3}{8}$ x $3\frac{1}{2}$ " SHCS (S270) thru the front top bolt hole. Thru the rear of the bracket use the provided Steel Bushing and one $\frac{3}{8}$ " lock nut. (S666)




Photo-12 Install the Alternator Side Support (20252-A). Thru the top back of the Power steering Bracket use one M8 x 120mm Hex Bolt (S559) and a TP3.625 Steel Spacer. Thru the lower hole use a $\frac{3}{8}$ x $\frac{3}{4}$ " SHCS (S244) Its best to install all bolts at the same time and leave them loose for proper alignment.



Photo13 Mounting the A/C Unit. Remove the A/C bracket ear from the water pump leaving a Alt ear on tight, thru the rear ear of the A/C unit use a M8 x 120mm hex bolt then reinstall the A/C ear to the water pump.




Photo 14 Installing the A/C rear and side supports, Mount the rear A/C support (20254-B) to the outer head bolt using a $\frac{3}{8}$ x 1" Hex bolt (S312) then from the rear of the bracket run a M8 x 120mm SHCS (S557) thru the rear support and thru the side support (20254-A). The side support mounts between the two ears of the A/C unit. Then mount the lower support to the tensioning bracket with a $\frac{3}{8}$ x $\frac{3}{4}$ " Button head screw (S316) as shown.





Photo 15 Mount the upper support (20255-A) use (2) $\frac{1}{4}$ x $\frac{5}{8}$ " Flat head Bolts (S120)



Photo 16 Install the Belt 62" for kits with Power Steering and 61" for non Power Steering kits.

Using a socket and driver pull back on the spring loaded tensioner and slide the belt into place. Release the tensioner. Install the tensioner cover.




Fig 17. Place the compressor clutch cover (394-A) onto the compressor clutch and align. Thread the three (3) (S520) M6 - 1.0 x 16mm Button Head Bolts. through the cover and into the clutch and tighten. **Caution - Do not over-tighten!**

Tighten alternator pulley nut (impact to 90 ft. pounds). Check and tighten all bracket bolts and alternator and A/C lower mounting bolts. Turn engine over once by hand to check for any belt rubbing and proper belt alignment. Run engine three minutes and check belt tension again.

Install Alternator Pulley cover (306-A) with three socket head cap screws (S028).

Final Assembly

If you are going to be installing your air conditioning hoses and charging the system at this time, remove the cover plate on top of the compressor body. Install the (P417) A/C adapter lines, hoses and connect clutch wire and charge system.

Important: If you are NOT installing hoses and charging the system at this time, leave cover plate on compressor. Do not connect the clutch wire or apply power to clutch wire without the hoses connected and the system charged – **Serious damage will occur to compressor.**

MARCH PERFORMANCE, INC. • 16160 PERFORMANCE WAY • NAPLES, FLORIDA 34110
LIMITED WARRANTY

March Performance warrants to the original retail purchaser that for a period of ninety (90) days from the date of purchase, March Performance will repair or replace, at their option, any Product, which is found to be defective in material or workmanship.

Exclusions from Warranty Coverage

March Performance does not warrant any Product that is damaged from abuse, misuse or misapplication or not used for its intended purposes.

This Limited Warranty does not cover or apply to any damage or loss sustained to the engine or any other parts which may have been caused by the defective Product and does not cover or apply to any personal injury, labor charges or any other incidental costs for damages caused by the defective Product. THIS IS THE ONLY EXPRESS WARRANTY GIVEN WITH RESPECT TO YOUR PRODUCT. ALL OTHER EXPRESS WARRANTIES, GUARANTEES, OR STATEMENTS REGARDING THE PRODUCT, WHETHER WRITTEN OR VERBAL, ARE HEREBY DEEMED NULL AND VOID AND OF NO EFFECT.

Normal wear and tear and damage to the Product not caused by March Performance are also excluded from this Warranty.

DISCLAIMER OF OTHER WARRANTIES

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW, ANY IMPLIED WARRANTY WHETHER OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR WARRANTY, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY WILL LAST SO THAT THE PRECEDING LIMITATION MAY NOT APPLY TO YOU.

Limitation on Remedies

REPAIR OR REPLACEMENT AS PROVIDED IN THIS WARRANTY IS YOUR EXCLUSIVE REMEDY. MARCH PERFORMANCE SHALL NOT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGE FOR BREACH OF ANY EXPRESS OR IMPLIED WARRANTY ON THE PRODUCT. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OF CONSEQUENTIAL DAMAGES SO THE PROCEEDING LIMITATIO OR EXCLUSIONS MAY NOT APPLY TO YOU. YOU HAVE NO RECOURSE OR REMEDY FOR DAMAGE OR DEFECT CAUSED BY MISUSE, ABUSE OR NEGLIGENCE.

THIS WARRANTY GIVES YOU SPECIFIC RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH MAY VARY FROM STATE TO STATE.

Your Responsibilities:

1. Use and install the Product only for its intended purpose.
2. To avail yourself of this Limited Warranty, return the Product with a copy of the paid receipt, postage paid to:

**MARCH PERFORMANCE
16160 PERFORMANCE WAY
NAPLES, FL 34110**

3. When returning the Product, you must follow the directions set forth on the Warranty/Return Form on the reverse side of this Limited Warranty. If you no longer have the Warranty/Return Form, one may be obtained by contacting March Performance during normal business hours at: (888) 729-9070.
4. Shipping and/or transportation costs returning the Product to March Performance and any damage caused during shipping are your responsibility. March Performance will pay for shipping and/or transportation costs incurred in returning the Product to you.

LIMITED WARRANTY WARRANTY/RETURNS FORM

No product mounted is considered for credit unless it is a manufacturer defect.

All products returned for any reason must reference an authorization number (RGA). The RGA number is obtained by calling place of purchase during normal business hours. **Any product returned without the RGA# written on the return package next to the return shipping label will be refused.**

All returns must ship via UPS and be properly packaged in the original carton. Return freight charges are the responsibility of the customer unless the product was shipped in error.

March product returned after (1) year from date of purchase will not be accepted unless it is found to be a manufacturer defect. **The customer must include a written statement describing the alleged product defect.** The complete Limited Warranty is set forth on the reverse side.

- 100% credit issued on manufacturer defects
- 20% return fee on all reshelvable product
- 70% return fee on all repairable product

NO CREDIT WILL BE ISSUED ON RETURNED PRODUCT BEYOND REPAIR

March Performance thoroughly inspects all returns. It is the sole discretion of March Performance in determining the condition of all returned merchandise. To receive replacements at no charge the original product must first be received and inspected by March Performance for determination. Immediate replacements may be purchased and later credited upon inspection determination.

Please Complete the Information below, detach and include with returned product.

RGA# _____ CT# _____ Issued by: _____ Date _____
Purchaser's Name _____ Phone _____
Address _____
Purchased Directly Through _____ Invoice# _____
Product ID _____ Invoice Date _____
Reason _____

**** MOUNTED PRODUCTS ARE NONREFUNDABLE ****