



DODGE CHARGER

1971 R/T & 500

1972 RALLYE w/LED reverse

Two Panel Sequential LED Tail Light Kit Installation Guide

Kit Contents:


- **2** LED panels
- **6** rubber grommets
- **1** power wire with t-tap
- **1** 24" driver side LED harness, 24"
- **1** 48" passenger side LED harness, 48"
- **2** LED extension harnesses, 12"
- **1** harness crimp kit

PN 1200271

Note

The LED boards are shipped with the slide switch set to Sequential mode. We recommend that all slide switches be set to the same setting (either standard or sequential).

Please follow all local laws concerning exterior lighting.



Hint

You may begin with the LED panel installation, however, you will need to complete the wiring modifications before the LED panels and housings are paired as one. Read over the entire instruction guide to determine the method that works best for you.

Note

A wire diagram of the LED panel's harness spliced into the car's stock harness is on the last page.

LED PANEL INSTALLATION

1. Cut off the power to your car.

Disconnect the negative terminal from the battery, which will cut off the power in your car. To verify that the power is disconnected, press the brake pedal; your brake lights should not turn on.

2. Remove the current taillights.

Remove the light sockets from the taillight housings. As a safety precaution, remove the bulbs from the sockets. Put them aside since they will no longer be needed. Remove the tail light housing assembly from the car and separate the lens from the housings.

3. Plug in extension wires, grommets.

Feed the extension wires through the socket hole. Wrap the rubber grommet around the wires and press it into the socket hole. Once the LED panels are in place for good, you will still be able to easily plug and unplug the harness and remove the housing assemblies.


Hint

It is best to use a small flat head screw driver to work the grommets onto the socket holes.



4. Test fit the LED panels.

Test fit the LED panels into the housing. The panel will fit nicely around the housing screw studs. The better the alignment is the better it will look behind the lens.



5. Mount the LED panels.

Peel off the protective strip from the double sided tape and mount the LED panels into place. The lens gasket should fit nicely around the LED panels without interfering with any of the LEDs.



1. Review the wiring diagrams found on the last page.

Each LED panel needs six connections. Listed are the LED harness colors and their respective function. Note: Depending on make and harness, colors may not match.

RED	- Constant 12 volt power source.
BLACK	- Grounded to body.
YELLOW	- Running/parking light signal.
GREEN	- Driver side turn signal.
BROWN	- Passenger side turn signal.
BLUE	- Reverse light signal.

2. Find and access the taillight wires.

Pick a point in the rear body panel between the driver's side quarter panel and the driver's side taillight housing assembly and remove the cloth tape to expose the taillight wires.

3. Splice the LED SIGNAL wires into the stock SIGNAL wires. Match the LED harness to the corresponding stock harness as shown below.

LED Harness	Function	Stock harness	Notes
 Brown	Passenger side turn signal/ Brake light signal	 Brown	The light socket ends on the car harness can be removed.
 Green	Driver side turn signal/ Brake light signal	 Green	The light socket ends on the car harness can be removed.
 Yellow	Running/Park signal	 Black	Running light wires. THIS IS NOT THE CAR'S GROUND.
 Blue	Reverse light signal	 Violet	The light socket ends on the car harness can be removed.
 Red	Constant 12 volt		Find power at fuse panel/trunk light/dome light/fused battery feed.
 Black	Ground		Ground to Body/chassis

Note about brake lights

There is no dedicated Brake light signal wire. When the brake pedal is pressed the brake switch sends power into the turn signal switch and then power through both the driver and passenger signal wires to activate the brake lights.

4. Connect all the ground wires.

Connect all the ground wires together. Bolt them to the trunk latch support along with the original rear body harness ground. The ground connection must be good in order to operate the LED tail lights.

5. Supply the LED panel harnesses with a constant 12 volt feed using the included **Orange power wire and T-Tap.**

An Orange power wire is supplied along with a T-Tap. The orange power wire must be powered with a constant 12 volt battery supply for the LED circuitry to operate properly. You can use the included T-Tap connector to splice to a constant power source, like the dome light, trunk light, fuse box, etc.

Splice the T-Tap connector over the constant power source, then plug the orange wire into the T-Tap. The other end of the orange power wire is tied in with the orange wires of all the LED panel harnesses.



1. Insert wire into T-Tap



2. Crimp with pliers



3. Plug connector into T-Tap

6. Tuck and secure the spliced wires.

Take the spliced sections and fold them over to one side and tape them in place. This will allow you to place the wiring into loom or wrap the LED panel wiring tightly away.



1. Fold wires to one side.



2. Secure with electrical tape.

Note

The LED light kits are designed for best performance when use an electronic no-load flasher. Shown here is an optional electronic no load flasher available from DIGI-TAILS, (PN 20-F2)



If you decide to use a stock bi-metal flasher, we recommend a standard-duty flasher instead of a heavy-duty flasher. If your turn signal circuit includes front and rear LED turn signals, the circuit will not have enough resistance load to operate a heavy-duty bi-metal flasher, so the no-load flasher will be required for both the turn signal and emergency flashers.

