

56444 Included Items

- Wire Harness with Tail Light Converter
- Battery Connection Wiring
- Fuse Holder
- Fuse
- Wire Crimp Ends
- Wire Ring Terminal
- Double-Sided Tape Square
- Mounting Hardware
- Wire Ties
- Dust Cover



CIRCUIT PROTECTED CONVERTER SYSTEMS

This product has been 100% tested under the full-rated load at the factory. The wire harness included as part of your tow package includes an in-circuit fuseholder that provides critical circuit protection.

If a short circuit or overload situation occurs in a trailer lighting circuit, the module is designed to shut the circuit down to protect the tow vehicle and module.

If tow vehicle lamps are shorted and the tow vehicle is not working, what power left to the trailer circuit for a few seconds then by the circuit again.

If trailer lamps return to normal function the light has been corrected.

If lamps light for a few seconds and then go off:

1. Check ground wire on both the tow vehicle and trailer.
2. Check for correct air overhead condition (too many bulbs).

If the circuit fails to light:

1. Check tow vehicle fuses.
2. Check trailer for correct connections.
3. Check the trailer lamp bulbs.
4. Check ground wire on both the tow vehicle and trailer.
5. Locate and correct a short.

Note: Using a tester can help confirm system function. If possible, please use our trailer air/water/electrical system. Repairs: This is a tow light trailer wiring and requires trailer wiring.

OMP P101-04

